


COMPASS SWING FLOWCHART



NOTE: Deviation = Compass Heading minus Magnetic Heading [D = (CH - MH)].